

For the Hunter-Pro Series and Captain 8 Intruder Alarm Systems



Installation Guide



Table of contents

Introduction	2
Features	2
Content of the product package	2
Technical specifications	2
Quick Reference Guide	3
The LEDs	3
Installation	3
Serial2Net Settings	4
Advance(d) Settings	5
How to reset the MWA500	5

Introduction

This guide will help you through the installation and configuration of the MWA500 wi-fi and Ethernet module. It allows users of the Hunter-Pro Series and Captain 8 intruder alarm systems, to use the *PIMAlink 3.0* app and cloud service.

The MWA500 is configured through a web browser.

Features

- Multiple Wi-fi standards support
- Ethernet connection
- Mounted in the enclosure of the control panel
- Easy web browser configuration

Content of the product package

MWA500 module, mounted on a bracket.
 Antenna
 Screws
 This guide

Technical specifications

Network Standard	• Wireless: IEEE 802.11n, IEEE 802.11g, IEEE 802.11b
	• Ethernet: IEEE 802.3, IEEE 802.3u
Transmission Rate	11n: maximum up to 150Mbps
	 11g: maximum up to 54Mbps
	11b: maximum up to 11Mbps
Frequency Range	2.4 - 2.4835GH
Interface	10/100Mbps, LAN/WAN, Multiplex
Antenna	External
Temperature	-10 to +50 °C
Humidity	90%, non-condensed

Quick Reference Guide

The LEDs

Label	Color	Indication					
Power	Red	Voltage OK					
LAN	Green	LAN connection OK					
Wifi	Green	Wi-fi connection OK					
Wifi	Green	Wi-fi connection Ok					



Installation



- Disconnect the control panel from AC and battery power prior to installation.
- Beware not to touch the antenna's wire connecter.
- 1. Pass the antenna through the hole on the top side of the control panel's enclosure, from inside out, and fasten the module with the two supplied screws. If a radio transmitter or a cellular module are installed, break one of the knockouts.
- 2. Connect the wire harness between the module and the SERIAL (J4) connector on the control panel.
- 3. Connect the control panel to power. The LEDs on the MWA500 module should turn on.



Figure 2. Mounting diagram

- 4. Select the wi-fi network icon on your PC/laptop's desktop tray, to view the list of the available wi-fi modules.
- 5. Select *HI-LINK_XXXX*. If *HI-LINK* is not on the list, make sure the module is up and running. If it is, the signal may be not strong enough.
- 6. Enter 12345678 in the PIN code field and select Connect.

- 7. Open a web browser, type the IP address 192.168.16.254 (the module's default address) and press *Enter*, to open the module's interface.
- 8. In the login window that opens up, enter *admin* as username <u>and</u> as password, and select *Sign in.*

Serial2Net Settings

1. Select S*erial2Net Settings* on the left pane and set the parameters, described in the table below.

No.	Field	Settings					
1	NetMode	• For Wi-fi mode, select <i>WIFI(CLIENT)-SERIAL</i>					
		For Ethernet mode, select ETH-SERIAL					
2	SSID	Press Scan and select your wi-fi module from the network list.					
3	Encrypt Type	Select WPA2 AES					
4	Password	Enter a router's password					
5	ІР Туре	Select DHCP					
6	IP Address						
7	Subnet Mask	These severations are visible as he from each of CTATIC					
8	Default Gateway	in <i>IP Type</i>					
9	Primary DNS Server	III IF Type.					
10	Secondary DNS Server						
11	Serial Configure	Enter 2400,8,n,1					
12	Serial Framing Length	Enter 256					
13	Serial Framing Timeout	Enter 2000					
14	Network Mode	Select <i>Client</i>					
15	Remote Server Domain/ IP	Enter <i>force.pimalink.com</i>					
16	Locale/Remote Port Number	Enter 13000					
17	Network Protocol	Select TCP					
18	Network Timeout	Enter θ (zero)					

Hi-Lin	k	TM	wı	RELES	S-N	ROUT	ER IE	EE 802.11N		
English 简体中文	HLK-RM04 Serial2Net Settings									
HLK-RM04 Serial2Net Settings	1	NetMode:	1	WIFI(CLIENT)-SEF	RIAL ¥				
Serial2Net UART 2 Settings	2 3 4 5	Encrypt Type: Password: IP Type:		WPA2 AES		•		Scan		
		IP Address: Subnet Mask: Default Gateway: Primary DNS Server:								
	10	Secondary DNS Server:		8.8.8.8						
	11 12	Serial Configure:	2400 256	ent),8,n,1		2400,8,n,1				
	13	Serial Framing Timeout:	ut: 2000 milliseconds			2000 timeout)	milliseconds (< 256, 0 for no			
	14 15	Network Mode: Remote Server Domain/IP:				Client - force.pimalink.com				
	16 17	Locale/Remote Port Number: Network Protocol:	tcp	 Do not change 		13000 TCP •				
	18	Network Timeout	0 se	conds		0 timeout)	seconds	s (< 256, 0 for no		
						Apply C	ancel			

2. Press Apply to save and reboot the module, and wait for the screen to refresh.

Advance(d) Settings

- 1. Select Advance Settings on the left pane.
- 2. Select Disable in TCP Client Auto Check, press Apply, and wait for the screen to refresh.



How to reset the MWA500

To reset the module to factory default settings, follow the next steps.

- 1. While the module is connected to power, press and hold the *Reset* button (see *Figure 1*) for 10 sec.
- 2. Wait two seconds.
- 3. Press and hold the *Reset* button again and wait for the two green LEDs to extinguish. The module will now be reset.

MWA500 Module Installation Guide

Limited support notice:

Due to the diverse mix of networks, we are not able to offer support on routers, modems, switches or any other network/internet related devices or services.

Our support for internet or network related features, that are not directly related to the product are limited.

The following must be completed before calling our support team with network/internet related features:

- 1. Your network/internet must be configured and working
- 2. IP address and port number for the product must be pre- configured on the network
- 3. Also, have the following information available: default Gateway, Subnet mask, port numbers and all other network information

Limited Warranty

PIMA Electronic Systems Ltd. does not represent that its product may not be compromised and/or circumvented, or that the Product will prevent any death, personal and/or bodily injury and/or damage to property resulting from burglary, robbery, fire or otherwise, or that the Product will in all cases provide adequate warning or protection. The User understands that a properly installed and maintained equipment may only reduce the risk of events such as burglary, robbery, and fire without warning, but it is not insurance or a guarantee that such will not occur or that there will be no death, personal damage and/or damage to property as a result.

Read this guide in its entirety before attempting to program or operate your system. Should you misunderstand any part of this guide, please contact the supplier or installer of this system.

Copyright © 2020 PIMA Electronic Systems Ltd. All rights reserved. E&OE



PIMA Electronic Systems Ltd. www.pima-alarms.com 5 Hatzoref Street, Holon 5885633, Israel. Tel: +972.3.6506414 Fax: +972.3.5500442 Email: support@pima-alarms.com



Revision: B4, XX en, Oct 2022